MX400SMP Surface Mount Preamp

Permanent mount for conference tables or lecterns. Includes LED logic input.



MX400SMP Surface Mount Kit

Installation



Note: Over tightening the wing nut reduces shock isolation.

Caution: To prevent bending pins, line up key with notch and seat connector fully before twisting to lock.

MX400SMP Pin Assignments



DIP Switches

Set DIP Switch 1 up to engage the low cut filter, which attenuates frequencies by 6 dB per octave below 150 Hz.



Switch	Down (default)	Up
1	Full frequency response	Low cut filter
2	LED steady	LED flashes

LED Logic

To operate the LED indicator, use the included 5-pin XLR connector to wire the microphone to an automatic mixer or other logic device.

Note: Connect the LED IN to the gate output to illuminate the LED when the channel is gated on.

Do not use the relay ports on Crestron and AMX devices. Use the I/O logic ports instead.

The LED logic may not function when connecting to devices that do not have internal "pull-up resistor" logic circuits, such as ClearOne DSP products. External pull-up resistor circuits can be added for each microphone. Visit www.shure.com/FAQ for de-tailed instructions.



Logic Connection

Connection to device with internal "pull-up resistor" logic circuit

MX405, 410, 415	
Logic LOW (0 V)	Logic HIGH (+5 V)

MX405, 410, 415	
	No contraction of the second s
Green	Red
MX405R, 410R, 415R	
Logic LOW (0 V)	Logic HIGH (+5V)
No the second se	No contraction of the second s
Red	Off/flashing

MX400DP Desktop Base

The MX400DP moveable desktop base includes a configurable mute button with logic output.



MX400DP Desktop Base

Installation



Caution: To prevent bending pins, line up key with notch and seat connector fully before twisting to lock.

Cable

The 20 ft. attached cable is terminated with a 3-pin XLR connector. For logic applications, open the XLR connector to access the three unterminated logic conductors.



Wire Color	Function
Red	Audio +
Black	Audio –
White	SWITCH OUT
Orange	LED IN
Green	Logic Ground
Shield	Mic Common Ground

MX400DP Pin Assignments



3-Pin XLR

MX400DP DIP Switches

Caution: Failure to reinstall the setscrew will reduce RF immunity.



Switch	Down (default)	Up
1	Momentary	Toggle
2	Push-to-Mute	Push-to-Talk
3	Local Mute	Logic Control

Switch	Down (default)	Up
4	Full Frequency Range	Low Cut Filter (attenuates 6 dB per octave be- low 150 Hz)
5	LED Steady	LED Flashes

Local Mute Control

The microphone ships configured for local (manual) mute control (**DIP Switch 3 down**). In this mode, the *PUSH* button on the microphone mutes the audio signal at the microphone. Audio is not sent to the audio outputs when muted.

In this configuration, the LED color reflects the microphone state, as controlled by the user with the PUSH button.



Microphone Status	MX405, 410, 415	MX405R, 410R, 415R
Active	Green	Red
Muted	Red	Off/flashing

Button Configuration

For local mute control operation, use DIP Switches 1 and 2 to configure the button behavior.

Button Behavior	SWITCH OUT Logic Signal	DIP Switch Setting
Momentary: push-to-mute (as shipped).	When pushed, SWITCH OUT (red wire) falls	ON 1 2 3 4
Momentary: push-to-talk	to 0 V. When released, SWITCH OUT re- turns to +5 V.	ON 1 2 3 4

Button Behavior	SWITCH OUT Logic Signal	DIP Switch Setting
Toggle: Push and release to toggle the mi- crophone on or off. Mic is active when powered on.	Push and release sets SWITCH OUT to 0 V. Push again to toggle back to +5 V.	ON 1 2 3 4
Toggle: Push and release to toggle the mi- crophone on or off. Mic is mute when powered on		ON 1 2 3 4

Logic Mute Control (Automatic Mixing)

Set **DIP Switch 3 up** to configure the microphone for logic control applications where audio from the microphone is muted by an external device, such as an automatic mixer. In this mode, the local mute function of the *PUSH* button is bypassed (the microphone always sends audio) and the LED does not respond directly from pushing the button.

As required by the installation specifications, wire the SWITCH OUT conductor in the microphone cable to the automatic mixer or other TTL logic device. When the talker presses the button on the microphone, it changes the voltage level at the SWITCH OUT conductor, which signals the device to mute audio for that channel or perform some other function.

To control the LED on the microphone, wire the LED IN conductor to the gate output on the automatic mixer (or any TTL logic device).

Button Configuration

For logic control operation, DIP Switch 1 determines the button behavior (DIP Switch 2 has no effect).

Button Behavior	DIP Switch Setting
Momentary: When pushed, SWITCH OUT (red wire) falls to 0 V. When released, SWITCH OUT returns to +5 V.	ON 1 2 3 4
Toggle: Push and release sets SWITCH OUT to 0 V. Push again to toggle back to +5 V.	ON 1 2 3 4

Controlling the LED Using Logic LED IN

When configured for logic mute control, connect the LED IN conductors to an external switch, relay, or a TTL gate (gate out) on an automatic mixer. The MX400DB contains an internal pull-up resistor circuit.

- The LED illuminates green/red when the MX396 LED IN is grounded (orange wire connected to the green wire).
- The LED illuminates red/off when LED IN is lifted (orange wire is NOT connected to the green wire).

Cable

MX400DP

6.1 m (20 ft) attached cable with shielded audio pair terminated at a 3-pin male XLR and three unterminated conductors for logic control

Environmental Conditions

Operating Temperature	–18–57°C (0–135°F)
Storage Temperature	–29–74°C (–20–165°F)
Relative Humidity	0–95%

Power Requirements

. Phantom Power

48-52 VDC, 8.0 mA

MX400DP	0.516 kg (1.138 lbs)
MX400SMP	0.125 kg (0.275 lbs)

Logic Connections

LED IN	Active low (\leq 1.0V), TTL compatible. Absolute maximum voltage: -0.7V to 50V.	
LOGIC OUT	Active low (\leq 1.0V), sinks up to 20mA, TTL compatible. Absolute maximum voltage: -0.7V to 50V (up to 50V through 3k Ω).	

Mute Switch Attenuation

-50 dB minimum

Output Impedance 170 Ω

Output Configuration Active Balanced



